


DELCO E81 IROM MPC5676 BENCH GM

**plugin 1706**




DELCO E81 IROM MPC5676 BENCH GM



## DIRECT CONNECTION

For the connection use the cable F32GN037C/D connected to the ECU.  
Make sure that the POWER led (red) on Trasdata is ON

| COLORE FILO<br>WIRE COLOUR     | DESCRIZIONE<br>DESCRIPTION               |                                                                                     |
|--------------------------------|------------------------------------------|-------------------------------------------------------------------------------------|
| ROSSO<br>RED                   | POSITIVO DIRETTO<br>POWER BATTERY        |  |
| ARANCIO<br>ORANGE              | POSITIVO SOTTO QUADRO<br>POWER SWITCH ON |                                                                                     |
| NERO<br>BLACK                  | MASSA<br>GND                             |                                                                                     |
| GIALLO<br>YELLOW               | KLINE                                    |                                                                                     |
| VERDE<br>GREEN                 | CAN LOW                                  |                                                                                     |
| BIANCO<br>WHITE                | CAN HIGH                                 |                                                                                     |
| GRIGIO<br>GREY                 | POL4<br>BOOT                             |                                                                                     |
| BLU<br>BLUE                    | POL5<br>CNF1                             |                                                                                     |
| VIOLETTA/GRIGIO<br>PURPLE/GREY | TENSIONE PROG.<br>PROG. VOLTAGE          |                                                                                     |
| MARRONE<br>BROWN               | RESET                                    |                                                                                     |

## ECU CONNECTOR

