

1 BOSCH BMS T1 IROM TC1797 EGPT SMART

1.1 PLUGIN 1880

1.2 CONNECTIONS

1.2.1 EGPT CONNECTION

The following cables must be used to communicate correctly with the ECU:



WIRE COLOUR		DESCRIPTION
	Red	+12 V
	Black	GND
	Green	CAN L
	White	CAN H
	Grey	GPT0
	Blue	GPT1



ATTENTION

For further information on the use of the F34NTA22-S2/S3/S5/S6 cables, see the [article](#).



BOSCH BMS T1 IROM TC1797 EGPT SMART

